

PCMflash module 60

PSA DCU102/SID208


Contents/Оглавление

Contents/Оглавление.....	2
PSA DCU102	3
PSA SID208	4

PCMflash

Engine Control Unit

DCU102



+12V	T3: H2; T2: G2	CAN-L	T2: B4
GND	T3: H1	CAN-H	T2: A4
K-LINE	T2: J2		

PSA

pcmflash.ru

v.1


2022-10-30

PCMflash


Engine Control Unit

SID208


T1




T2



T3



+12V	T1: 5, 39	CAN-L	T1: 11
GND	T1: 3	CAN-H	T1: 10



Switching to BSL mode required to Unlock ECU. Solder resistors as shown above /
 Для разблокировки ЭБУ переведите его в BSL режим как указано выше.

PSA

pcmflash.ru

v.1

2022-10-31